
Endress+Hauser
People for Process Automation

Basic version

General spare parts: XPC0003

Spare parts depending on material: XPC0002 (PP), XPC0004 (1.4404), XPC0005 (2.4602), XPC0006 (PVDF), XPC0007 (PVDF conductive), XPC0008 (PEEK)



Immersion chamber version

General spare parts: XPC0003

Spare parts depending on material: XPC0002 (PP), XPC0004 (1.4404), XPC0005 (2.4602), XPC0006 (PVDF), XPC0007 (PVDF conductive), XPC0008 (PEEK)

